

733 Dual Remote Splitter Kit for 724 Workstation Monitor Instructions

Contents:

- 1 - SCS [733](#) Remote Input Jack with cable
- 1 - Plastic Hole Plug-Black
- 2 - Screw, Round Head
- 2 - Cable Clip

To connect a second remote input jack to a SCS [724](#) Workstation Monitor perform the following steps:

1. Mount the remote input jack using the two round head screws, at the desired locations within the length of the cable.
2. Ensure the cable is connected to the 733 Remote Input Jack.
3. Route the cable to the 724 Monitor and secure with cable clips.
4. Plug the other end of the cable into the socket identified 733 at the rear of the monitor.
5. Fully insert the plastic hole plug into the #2 of the existing remote input jack. Note: This action disables this connection, preventing simultaneous usage of the #2 input.

For additional information and a diagram showing how to create two separate workstations refer to the instruction manual for the 724 Monitor.

Limited Warranty, Warranty Exclusions, Limit of Liability and RMA Request Instructions

See the SCS Warranty -

<http://staticcontrol.descoindustries.com/warranty.aspx>

Made in China.