

# NuMicro<sup>®</sup> Family powered by Cortex<sup>™</sup>-M0

## Development Tools



### Selection Guide

Ordering Number	Content	Supported Devices	Description	Picture
<b>NuMicro_SDK</b>	<ul style="list-style-type: none"> <li>• Nu-Link</li> <li>• Nu-EVB</li> <li>• USB Cable</li> <li>• Setup CD</li> </ul>	NUC100 NUC120 NUC130 NUC140	<ul style="list-style-type: none"> <li>• An Evaluation/Development Kit for NuMicro</li> <li>• Keil MDK-ARM (evaluation version) included</li> <li>• Examples with source code included</li> <li>• Support ICP (In-Circuit Programming)</li> <li>• USB Plug &amp; Play</li> </ul>	
<b>NuTiny_SDK_100</b> <b>NuTiny_SDK_120</b>	<ul style="list-style-type: none"> <li>• Nu-Link-ME</li> <li>• Nu-Tiny-EVB</li> <li>• USB Cable</li> </ul>	NUC100 NUC120	<ul style="list-style-type: none"> <li>• An Evaluation/Development Kit for NuMicro</li> <li>• Keil RV/MDK (evaluation version) can be download from website</li> <li>• No ICP (In-Circuit Programming)</li> </ul>	
<b>Nu-Link</b>	<ul style="list-style-type: none"> <li>• Nu-Link</li> </ul>	NUC100 NUC120 NUC130 NUC140	<ul style="list-style-type: none"> <li>• USB ⇔ SWD bridge</li> <li>• Support ICP (In-Circuit Programming)</li> <li>• USB Plug &amp; Play</li> </ul>	
<b>Nu-EVB</b>	<ul style="list-style-type: none"> <li>• Nu-EVB</li> </ul>	NUC100 NUC120 NUC130 NUC140	<ul style="list-style-type: none"> <li>• An Evaluation/Development Board for NuMicro</li> <li>• SWD port for Nu-Link, Nu-Link-ME</li> <li>• JTAG port for U-Link or J-Link</li> <li>• USB to PC/Laptop through Nu-Link for debugging</li> <li>• USB Plug &amp; Play</li> </ul>	
<b>Nu-LB</b>	<ul style="list-style-type: none"> <li>• Nu-LB</li> </ul>	NUC100 NUC120 NUC130 NUC140	<ul style="list-style-type: none"> <li>• A Starter Kit made by Nuvoton</li> <li>• Keil MDK-ARM (evaluation version) included</li> <li>• Examples with source code included</li> </ul>	
<b>Nu-IAR_SKT</b>	<ul style="list-style-type: none"> <li>• M-Link</li> <li>• USB Cable</li> <li>• Setup CD</li> </ul>	NUC100 NUC120 NUC130 NUC140	<ul style="list-style-type: none"> <li>• Starter Kit made by IAR</li> <li>• IAR EWARM (evaluation version) Included</li> <li>• IAR C/C++ Compiler included</li> <li>• USB Plug &amp; Play</li> </ul>	
<b>Nu-Keil_SKT</b>	<ul style="list-style-type: none"> <li>• U-LINK-ME</li> <li>• MCBNUC1XX</li> <li>• USB Cable</li> <li>• Setup CD</li> </ul>	NUC100 NUC120 NUC130 NUC140	<ul style="list-style-type: none"> <li>• Starter Kit made by Keil</li> <li>• Keil MDK –ARM (evaluation version) included</li> <li>• ARM C/C++ Compiler included</li> <li>• USB Plug &amp; Play</li> </ul>	